

POOL 'SELF ASSESSMENT' CHECKLIST -

POOLS BUILT OR INSTALLED AFTER 1/05/2010

Australian Standard AS1926.1 - 2007 Amendment 1 and AS 1926.1-2012

Mir Sumon

M 0430973020

E: info@localpoolandspainspection.com.au

ABN: 56 799 566 424

www.localpoolandspainspection.com.au



Does your pool meet the safety standards?

The pool fence must be at least 1200mm high all the way around measured from the outside of the pool	<input type="radio"/> Yes	<input type="radio"/> No
If a boundary fence forms part of the pool fence, it must be at least 1800mm high measured from the inside of the pool area	<input type="radio"/> Yes	<input type="radio"/> No
The gap between the bottom of the fence and the ground is no more than 100mm.	<input type="radio"/> Yes	<input type="radio"/> No
The gap between all vertical or near vertical rails on the fence is less than 100mm.	<input type="radio"/> Yes	<input type="radio"/> No
There are no potential hand holds or foot holds within 900mm of the top of the pool fence in any direction.	<input type="radio"/> Yes	<input type="radio"/> No
There must be a 300mm clearance from the barrier inside the pool area	<input type="radio"/> Yes	<input type="radio"/> No
If perforated or mesh fencing is used, the holes must be 13mm or less	<input type="radio"/> Yes	<input type="radio"/> No
Your pool fence must be well maintained and in a good state of repair (eg no holes, broken rails or palings)	<input type="radio"/> Yes	<input type="radio"/> No
The gate must be self closing and latch by itself from any position, even resting on the latch	<input type="radio"/> Yes	<input type="radio"/> No
The gate latch must be working well so that the gate is secure and, once closed, can't be pulled open	<input type="radio"/> Yes	<input type="radio"/> No
The gate must open outwards, away from the pool.	<input type="radio"/> Yes	<input type="radio"/> No
The gap between vertical barriers of a gate must be no more than 100mm	<input type="radio"/> Yes	<input type="radio"/> No
The gate latch must be 1500mm above ground level, or if located inside the gate, 1200mm above ground level and at least 150mm below the top of the gate	<input type="radio"/> Yes	<input type="radio"/> No
Are you aware that it is dangerous and against the law to prop the gate open.	<input type="radio"/> Yes	<input type="radio"/> No
If a wall forms part of the barrier, there are no openings greater than 100mm	<input type="radio"/> Yes	<input type="radio"/> No
All windows can only open to a maximum of 100mm or the windows must be totally covered by bars or a metal screen	<input type="radio"/> Yes	<input type="radio"/> No
The height from the sill of the lowest opening panel of a window (to the pool area) has to be 1800mm from the floor	<input type="radio"/> Yes	<input type="radio"/> No
Your pool fence must be clear of any objects such as BBQs, trees, rocks, shrubs and deckchairs within 900mm from the top of the fence outside that could help a small child climb over the fence	<input type="radio"/> Yes	<input type="radio"/> No
For Indoor pool, door should not be open towards the pool.	<input type="radio"/> Yes	<input type="radio"/> No

If you have answered 'No' to any of the questions above, please contact us for further clarification Local pool and Spa Inspection. Our web site www.localpoolandspainspection.com.au.

M:0430973020

Email: info@localpoolandspainspection.com.au